

FERRARI® STAMOID

BEST PRACTICES CLEANING RULES IN 8 EASY STEPS

- 1 - Spread the material out on a flat surface. Dampen the fabric with clear water. Spray with IMAR Stamoid® Cleaner or add a diluted solution of soft soap liquid.
- 2 - Let the product work for 2 to 3 min., according to the degree of dirtiness.
- 3 - Rub the fabric using a soft bristle brush with rounded edges. Do not press hard on the brush, let the bristles do the work.
Important! Using any type of brush is forbidden for the STAMOID® SK range. Simply use a soft sponge.
- 4 - Thoroughly rinse with clear water to remove any remaining soapy solution. If the product is in contact with other materials, rinse immediately.
- 5 - In the event of heavy dirt accumulation, repeat the operation.
- 6 - Repeat points 1 to 5 of the operation on the underside of the fabric.
- 7 - Then hang up the FERRARI® STAMOID fabric until it is perfectly dry.
- 8 - Once the fabric is completely dry, you can reinstall it to protect your boat.

